

Torque Ratings Spring-Return Actuators

ACTUATOR MODEL	SPRING TORQUE INCH LBS.	AIR TORQUE (PSI)													
		40	50	60	70	80	90	100	120	125	150	200			
33082SR80	START	20797	8341	12653	16964	21276	25588	29899	38523	40678	51457	73016			
	MIN.	8679	646	4312	7977	11641	15306	18972	26301	28134	37296	55620			
	END	10210	761	5073	9395	13696	18008	22320	30943	33099	43878	65436			
33082SR100	START	27111			15804	20116	24428	29739	37363	39518	50297	71856			
	MIN.	10846			2610	6274	9939	13604	20934	22767	31929	50253			
	END	12760			3071	7382	11694	16005	24629	26785	37564	59122			
33082SR125	START	35837													
	MIN.	13566													
	END	15960													
33082SR150	START	41110													
	MIN.	16278													
	END	19150													
33082SR200	START	55584													
	MIN.	21476													
	END	25266													
33102SR40	START	12566	14236	27829	34626	41422	48218	55015	68608	72006	88977	122979			
	MIN.	6027	6251	17805	23583	29359	35136	41763	52467	55356	69798	98683			
	END	7090	7355	20948	27745	34541	41337	49134	61727	65125	82116	116098			
33102SR60	START	19830	10093	23686	30482	37278	44075	50871	64484	67682	84853	118035			
	MIN.	9682	6251	17805	23583	29359	35136	40913	52487	55356	62305	91190			
	END	11390	7355	20948	27745	34541	41337	48134	61727	65125	73301	107283			
33102SR80	START	28644	16375	23172	29968	36764	43561	50357	63950	67348	84339	118321			
	MIN.	13770	4536	10313	16090	21867	27644	33421	44975	47863	57898	86783			
	END	16200	5337	12134	18930	25727	32523	39319	52912	56310	68116	102098			
33102SR100	START	33829	9604	16400	23197	29993	36790	43586	57179	60577	77568	111550			
	MIN.	17213	130	5906	11683	17460	23237	29014	40567	43456	52143	81027			
	END	20250	153	6949	13745	20542	27338	34135	47727	51125	61345	95327			
		40	50	60	70	80	90	100	120	125	150	200			