

Torque Ratings Spring-Return Actuators

| ACTUATOR MODEL | SPRING TORQUE INCH LBS. | AIR TORQUE (PSI) | | | | | | | | | | | | | | |
|----------------|-------------------------|------------------|----|----|----|----|----|-----|-----|------|-------|-------|-------|-------|--------|--------|
| | | 40 | 50 | 60 | 70 | 80 | 90 | 100 | 120 | 125 | 150 | 200 | | | | |
| 45102SR125 | START | | | | | | | | | | 51751 | 60653 | 78457 | 82908 | 105163 | 149673 |
| | MIN. | | | | | | | | | 3512 | 11078 | 26212 | 29995 | 48912 | 86745 | |
| | END | | | | | | | | | 4132 | 13034 | 30838 | 35289 | 57544 | 102054 | |
| 45102SR150 | START | | | | | | | | | | 49328 | 67132 | 71583 | 93838 | 138348 | |
| | MIN. | | | | | | | | | | 1452 | 16586 | 20369 | 39286 | 77119 | |
| | END | | | | | | | | | | 1709 | 19513 | 23964 | 46219 | 90729 | |
| 45102SR200 | START | | | | | | | | | | | | | | | |
| | MIN. | | | | | | | | | | | | | | | 134182 |
| | END | | | | | | | | | | | | | | | 47363 |
| 45122SR40 | START | | | | | | | | | | | | | | | |
| | MIN. | | | | | | | | | | | | | | | |
| | END | | | | | | | | | | | | | | | |
| 45122SR60 | START | | | | | | | | | | | | | | | |
| | MIN. | | | | | | | | | | | | | | | |
| | END | | | | | | | | | | | | | | | |
| 45122SR80 | START | | | | | | | | | | | | | | | |
| | MIN. | | | | | | | | | | | | | | | |
| | END | | | | | | | | | | | | | | | |
| 45122SR100 | START | | | | | | | | | | | | | | | |
| | MIN. | | | | | | | | | | | | | | | |
| | END | | | | | | | | | | | | | | | |
| 45122SR125 | START | | | | | | | | | | | | | | | |
| | MIN. | | | | | | | | | | | | | | | |
| | END | | | | | | | | | | | | | | | |
| 45122SR150 | START | | | | | | | | | | | | | | | |
| | MIN. | | | | | | | | | | | | | | | |
| | END | | | | | | | | | | | | | | | |
| 45122SR200 | START | | | | | | | | | | | | | | | |
| | MIN. | | | | | | | | | | | | | | | |
| | END | | | | | | | | | | | | | | | |