

Torque Ratings Spring-Return Actuators

ACTUATOR MODEL	SPRING TORQUE INCH LBS.	AIR TORQUE (PSI)														
		40	50	60	70	80	90	100	120	125	150	200				
26061SR60	START	3111	3303	4226	5150	6074	6998	7921	9769	10231	12540	17159				
	MIN.	1148	1281	2066	2851	3637	4422	5207	6777	7170	9133	13059				
	END	1350	1508	2431	3355	4279	5203	6126	7974	8436	10745	15364				
26061SR80	START	3675	2738	3662	4586	5510	6434	7357	9205	9667	11976	16595				
	MIN.	1641	801	1586	2372	3157	3943	4727	6298	6691	8653	12580				
	END	1930	943	1867	2791	3715	4639	5562	7410	7872	10181	14800				
26061SR100	START	5105		3221	4145	5069	5992	6916	8764	9226	11535	16154				
	MIN.	2049		372	1157	1943	2727	3513	5083	5476	7439	11365				
	END	2410		438	1362	2286	3209	4133	5981	6443	8752	13371				
26061SR125	START	5771			3478	4402	5326	6250	8097	8559	10868	15487				
	MIN.	2627			590	1376	2161	2946	4516	4909	6872	10798				
	END	3090			695	1619	2543	3466	5314	5776	8085	12704				
26061SR150	START	8356						5730	7577	8039	10349	14968				
	MIN.	3247						834	2319	2712	4675	8601				
	END	3820						982	2729	3191	5501	10119				
26061SR200	START	9802							6128	6590	8899	13518				
	MIN.	4214							1090	1483	3445	7372				
	END	4958							1283	1745	4054	8673				
26062SR40	START	5067	7164	9053	10943	12832	14722	16611	20390	21335	26059	35506				
	MIN.	1726	3723	5329	6936	8541	10148	11753	14965	15769	19784	27814				
	END	2030	4381	6270	8160	10049	11939	13828	17607	18552	23276	32723				
26062SR60	START	6954	5276	7166	9055	10945	12834	14724	18503	19448	24171	33619				
	MIN.	2771	2119	3725	5331	6937	8543	10149	13362	14165	18179	26210				
	END	3260	2493	4383	6272	8162	10051	11941	15720	16665	21388	30836				
26062SR80	START	9720		6462	8351	10241	12130	14020	17799	18743	23567	32915				
	MIN.	3944		1374	2980	4586	6192	7798	11010	11814	15828	23859				
	END	4640		1617	3506	5396	7285	9175	12954	13899	18622	28070				
		40	50	60	70	80	90	100	120	125	150	200				