

# Torque Ratings Spring-Return Actuators

ACTUATOR MODEL	SPRING TORQUE INCH LBS.	AIR TORQUE (PSI)															
		40	50	60	70	80	90	100	120	125	150	200					
26062SR100	START				6488	8377	10267	12156	15935	16890	21604	31051					
	MIN.				1394	2999	4606	6211	9423	10227	14242	22272					
	END				1640	3529	5419	7308	11087	12032	16756	26203					
26062SR125	START						10086	11975	15754	16699	21423	30870					
	MIN.						1327	2933	6145	6948	10964	18994					
	END						1562	3451	7230	8175	12899	22347					
2062SR150	START							9654	13433	14377	19101	28549					
	MIN.							957	4170	4972	8987	17018					
	END							1127	4906	5850	10574	20022					
26072SR40	START						6589	9176	11763	14351	16938	19525	22113	27287	28581	35049	47986
	MIN.						3507	5706	7906	10105	12304	14504	16703	21102	22201	27699	38696
	END						4127	6714	9302	11889	14476	17064	19651	24826	26119	32588	45525
26072SR60	START						4489	9176	9643	12231	14818	17406	19993	25168	26461	32930	45866
	MIN.						901	5997	5299	7498	9697	11897	14096	18495	19595	25092	36089
	END						1060	7056	6235	8822	11409	13997	16584	21759	23053	29521	42458
26072SR80	START						12691	5449	8037	10624	13211	15799	18386	23561	24854	31323	44260
	MIN.						5457	208	2408	4607	6806	9005	11204	15603	16703	22201	33197
	END						6420	245	2833	5420	8008	10595	13182	18357	19651	26119	39056
26072SR100	START						16162			9308	11895	14482	17070	22244	23538	30006	42943
	MIN.						6826			1657	3856	6056	8255	12653	13702	19251	30248
	END						8030			1950	4537	7125	9712	14887	16120	22649	35586
26072SR125	START						20309				10261	12848	15435	20610	21904	28732	41309
	MIN.						8534				331	2530	4730	9128	10228	14026	26722
	END						10040				390	2977	5565	10739	12033	16502	31438
26072SR150	START						23526						12222	17396	18690	25158	38095
	MIN.						10243						1994	6393	7493	12991	23987
	END						12050						2347	7522	8816	15284	28221
							40	50	60	70	80	90	100	120	125	150	200